



## POV H2O Pouch (POV162)

### PLEASE READ THE INFORMATION AND FOLLOW ALL INSTRUCTIONS BEFORE USING THIS PRODUCT.

**CARE:**

- Clean and inspect after every use.
- Store your equipment in a cool, dry place.
- Check all cables for cracks or exposed wires; if a cable is suspect, discard and replace.

**CAUTIONS:**

- Always replace frayed or damaged wires and broken plugs immediately.
- Do not short-circuit the metal contacts of the battery pack.
- Do not disassemble, deform, or reconstruct any part of the battery kit.

**NOTES:****TECHNICAL SPECIFICATIONS:**

- Bag Material: Plastic clear stuff
- Durability to jkjjgj meters deep.

**OPERATING INSTRUCTIONS:****Use:**

1. Open the end of the POV H2O Pouch by rotating the locking knobs to the open position (O).
2. Unscrew the top cap and remove the plastic valve cover and rubber insert.
3. Thread the AV cable through the top cap and out of the bottom of the POV H2O Pouch.
4. Connect the AV cable to the POV Recording unit and pull the recording unit into the bag. It is recommended that the LCD screen is visible on the side of the pouch with the V.I.O. logo.
5. Close the bag and set the locking knobs to closed ( C ).
6. Pull the AV cable through the bag completely and firmly.
7. Place the rubber insert and the plastic valve cover on the AV cable, between the Magnet Core and opening on the water bag.
8. Tighten the top cap on to the water bag opening. Be sure to have the Magnetic Core outside of the bag itself
9. Thread the belt through the side slits of the POV H2O Pouch, as well as the flap on the pouch itself.

**Tips:**

Make sure to wash the POV H2O Pouch if it has been used in Saltwater

Any rips or tears on the AV cable may result in water entering the recording unit.